

Medtec Stock PD168 Action Safe

Singer Associates

Medtec Stock Unit

Medtec Stock Unit

Quote No: 10040-0001 Job/Order No: 8077

AMBULANCE: PD-168-F PD-168, 168" x 96", Type I

05/05/2009

Page 1

PART NO	S	DESCRIPTION	QTY	ID
		== PD-168, 168" x 96", Type I - 8.714 03/19/08 == Medtec Display Vehicle for EMS Expo October 2008	1	MAC
		Whelen M series LED lights. Do not cut full 900 Series light cut outs. Whelen OS Marker/DOT Lights. Do not cut holes above driprail. Eberhard Handles, Latches and hardware in lieu of Trimark		
		Eberhard: 1033265 Outside locking handle 1033266 Inside locking handle 1033267 Inside NL handle 1033268 Outside NL handle		
		*** PRELIMINARY ADMIN/ COT INFORMATION ***	1	MAC
00-00-0010		PRODUCTION FACILITY, GOSHEN, IN.	1	MAC
01-00-0000		VIN #	1	MAC
		*** GENERAL VEHICLE DESIGN & REQUIREMENTS ***	1	MAC
10-06-2000		2008 Base Conversion, PD-168-F Type I	1	MAC
11-06-0950		72" Headroom (PD-168-F) Action Safe	1	MAC
12-00-1200		EXTERIOR "A" COMPARTMENTS - PASS. SIDE (72" HR) PD-168-F AS	1	MAC
12-02-0600		Type I, Class I, Two-Door Cab/Chassis Tech Requirements	1	MAC
		*** CHASSIS MAKE & MODEL ***	1	MAC
12-08-1600		Ford F-450 Cab/Chassis, 4 x 2, 2008, 189" WB, INSTRUCTION: 189" wheelbase 108"CA 16,000 LB GVW Front GAWR- 6,000# Rear GAWR-12,000#	1	MAC
12-13-0400		Rear Air Ride System With Lowering Kit, Kelderman - Low PSI light in front switch panel. - Dump automatically activated by the streetside rear entry door. - Dump cancel switch beside curbside rear entry door	1	MAC

PART NO	S	DESCRIPTION	QTY	ID
12-16-0100		Exhaust, Passenger Side Rear of Rear Axle	1	MAC
		*** CHASSIS COMPONENTS ***	1	MAC
14-18-0100		Sway Bar, No Aftermarket Sway Bars	1	MAC
14-22-0200		Shock Absorbers, OEM, Front & Rear	1	MAC
		*** CHASSIS INTERIOR COMPONENTS ***	1	MAC
16-02-2000		OEM AM-FM Radio & CD - Standard location	1	MAC
16-14-0400		Cab Sign, "No Smoking, Oxygen Equipped" & "Fasten Seatbelts" INSTRUCTION; (1) on top of floor console, at rearward edge, toward walkthru.	1	MAC
16-16-0200		Cab Flooring, OEM Carpeted	1	MAC
16-21-0000		Battery Switch - TST Commander 350 With 5 Minute Timer	1	MAC
16-24-0200		Summer Switch for Block Heater, Behind Driver's Seat	1	MAC
		*** CHASSIS EXTERIOR ACCESSORIES ***	1	MAC
18-06-0400		Wheel Simulators, Dicor - Stainless Steel	1	MAC
18-12-0200		Tire Fill Extensions (4) Dicor, For Rear Inside/Outside Tire	1	MAC
		*** 12 VOLT ELECTRICAL SYSTEMS AND COMPONENTS ***	1	MAC
20-02-0700		Standard Electrical System, Type I	1	MAC
20-08-0400		Install and Label Breakers on Driver's Side Front Console	1	MAC
21-02-0000		Portable Equipment Charging Circuits INSTRUCTION: (1) 20 amp circuit breaker. Run power wires from under front console to: (1) Circuit (power & ground) to front console labeled on both ends: "Portable Equipment Charging Circuit". (1) Circuit (power & ground) to behind rear switch panel labeled on both ends: "Portable Equipment Charging Circuit". (Requires optional inverter or battery charger for full function.)	1	MAC
22-02-0600		Sequencer/Load Manager, Main Master Emergency Functions INSTRUCTION: Medtec sequencer and load manager. Standard shedding sequence.	1	MAC
22-04-1000		Front Console, Center Cab Mount, Ford F-Series INSTRUCTION: Install standard floor-mounted console. Install Rocker style switch panel in dash. .125 aluminum black spray coated Medtec Part number 1003932	1	MAC
22-05-0100		Front Switch Panel, Standard Electrical System	1	MAC
22-09-0010		Voltmeter/Ammeter, Std. Inpower DSP-DSC1	1	MAC
24-02-1100		(2) Batteries, 1500 CCA INSTRUCTION: Dual OEM under hood	1	MAC
24-08-0300		Battery Conditioner, Inteli-Power #PD9130A, 30 Amp, Dual.	1	MAC

PART NO	S	DESCRIPTION	QTY	ID
		Installed behind the passenger seat.		
24-12-0500		Outlets, (3) - 12 Volt, Power Point Style, (ACTION SAFE) INSTRUCTION: (1) in ALS cabinet (1) on 2nd AA (1) on 3rd AA on rear wall SEE PRINTS	1	MAC
		*** 125 VOLT ELECTRICAL SYSTEMS AND COMPONENTS ***	1	MAC
26-06-0600		Inverter Pre-Wire Only, In D-2 Compartment INSTRUCTION: Pre-wire in the exterior D-2 compartment. (1) On/off switch in rear switch panel. LOCATION: Inverter prewire located at floor level in the back left corner of the compartment.	1	MAC
26-10-1200		Shoreline,20 Amp Kussmaul Super Auto-Eject, On Driver Side INSTRUCTION: (1) 125 volt 20 amp. (60Hz) Kussmaul Super Auto-eject Water-tight cover. Ship loose mating plug.	1	MAC
26-16-2700		Outlets, (3) Interior, 125 Volt AC (Action Safe) LOCATION: (1) in ALS (1) in 1st action area (1) in 3rd action area on back wall SEE PRINTS	1	MAC
26-22-0400		Spotlight, (1) Optronics "BlueEye 4000",Hand-Held, Hard Wire LOCATION: Wired to drivers seatbase. SHIP LOOSE HANGING HARDWARE.	1	MAC
		*** AUDIO WARNING DEVICES ***	1	MAC
28-02-1000		Siren & Amplifier, Whelen, #295HFSA7 Whelen #295HFSA7 Siren/Amplifier	1	MAC
28-04-0100		Horn Ring, Switch, Siren/Horn 2 Position INSTRUCTION: (2) position switch to toggle between siren/horn between each horn ring trigger. (1) switch in front switch panel	1	MAC

PART NO	S	DESCRIPTION	QTY	ID
28-06-0250		Speaker, Bumper Mounted, #SAP/SAD4314 Passenger side: SAP4314 Driver side: SAD4314	1	MAC
28-14-0200		Backup Alarm, EC520 With Auto Reset Switch INSTRUCTION: (1) Automatic reset cancel switch, mounted in front switch panel.	1	MAC
		* * * VISUAL WARNING DEVICES * * *	1	MAC
		PERIMETER WARNING LIGHTS - UPPER & LOWER LEVELS QTY. MODEL NUMBER DESCRIPTION		
		12 M9RS M9 SERIES SUPER LED (RED) STEADY BURN		
		1 M9AS M9 SERIES SUPER LED (AMBER) STEADY BURN		
		1 M9CS M9 SERIES SUPER LED (CLEAR) STEADY BURN		
		14 M9FC FLANGE KIT FOR M9 SERIES LIGHTS		
		2 M4RS M4 SERIES SUPER LED (RED) STEADY BURN		
		2 M4FC FLANGE KIT FOR M4 SERIES LIGHTS		
		4 M7RS M7 SERIES SUPER LED (RED) STEADY BURN		
		4 M7FC FLANGE KIT FOR M7 SERIES LIGHTS		
		2 50R03ZRR 500 SERIES TIR6 LED LIGHTHEAD (RED)		
		2 AFL530 LED FLASHER FOR ABOVE LIGHT HEADS AND LIGHTBARS		
		LED BRAKE/TAIL-TURN & BACK-UP, MARKER LIGHTING QTY. MODEL NUMBER DESCRIPTION		
		2 60R00XRR MAX POP. LED BRAKE/TAIL 600 SERIES		
		2 60A00TAR ARROW LED TURN 600 SERIES		
		2 60J000CR HALOGEN BACK-UP 600 SERIES		
		6 6EFLANGE FLANGE KIT FOR 600 SERIES		
		LED SCENE LIGHTING QTY. MODEL NUMBER DESCRIPTION		
		6 M9ZC M9 SERIES SUPER LED SCENE LIGHT		
		6 M9FC FLANGE KIT FOR M9 SERIES LIGHTS		
		M series LED lights. Do not cut full 900 Series light cut outs		
30-00-0001		No Steady Burn Light(s)	1	MAC
30-00-0010		Flasher, Whelen AFM560 (Std.)	1	MAC
30-03-1200	S	Clearance Lights, Whelen LED, (14) OS Series INSTRUCTION: (4) lights - two on each side, of upper body corner extrusions. (5) on the rear and (5) on the front, upper body extrusions.	1	MAC
		OSA00MCR OSR00MCR		
30-09-0200		Lights, Whelen 600 LED, Stop/Tail/Turn With Arrow LOCATION: With Flanges. Backup lights - halogen. Lights on rear of module box in standard location. SEE PRINT	1	MAC
		CHASSIS GRILLE LIGHTS	1	MAC

PART NO	S	DESCRIPTION	QTY	ID
30-12-0030		Grille Lights Installed on OEM Grille Grille lights to be installed on the lower section of the chassis grille at the far left and far right sides.	1	MAC
30-16-4400		Grille Lights, (2) Whelen 500 LED (TIR6), Red INSTRUCTION: With Bezels Red LED Red Lens	1	MAC
INTERSECTION LIGHTS			1	MAC
30-18-1500	X	Intersection Lights, (2) Whelen M4, Red Lens INSTRUCTION: With Flanges.	1	
LIGHTBARS - FRONT OF VEHICLE			1	MAC
30-30-2800	S	Front Lightbar, Whelen LED, Justice INSTRUCTION: (1) switch in front switch panel. Cab roof mount Whelen LED Lightbar Model: JE2RRRR 56" Justice LED Lightbar	1	MAC
FRONT OF BODY LIGHTS			1	MAC
32-02-9800	X	Frnt Bdy Lights, (5) Whelen M9 LED R/R/C/R/R LOCATION: Upper front of module INSTRUCTION: M9 Series LED lights with flange matching lens colors	1	
SIDE OF BODY WARNING LIGHTS			1	MAC
32-16-9900	X	Side Body Lights, (4) Whelen M9 Series, Red W/ Flange LOCATION: With Flanges (2) Streetside (2) Curbside Lense Colors: Red	1	
32-18-9900	X	Side Turn Lights -- Whelen M7 Red Led INSTRUCTION: With Flanges. Red Lenses. (1) Each side of body at rear. Steady burn with DOT lights. Flash with turn signals.	1	
SIDE SCENE LIGHTS			1	MAC
32-22-9900	X	Scene Lghts - Whelen M9 Scenelight LOCATION: Upper module body curbside and streetside	1	

PART NO	S	DESCRIPTION	QTY	ID
32-24-0200		Scene Light Activation - Standard INSTRUCTION: Curbside scene lights to activate with side entry door. Rearmost scene lights to activate in reverse.	1	MAC
		REAR BODY LIGHTS	1	MAC
		REF: 0600/2000/3200/3400		
34-06-1800	X	Rr Bdy Lgts, (3) Upper, Whelen M9 Series LED, R/A/R W/Flange LOCATION: With Flanges (2) Red LEDs/Lenses on rear upper corners, of module box. (1) Amber LED/Lens on rear upper center, of module box.	1	
34-08-9800	X	Load Lights, Upper - Whelen M9 Scenelight INSTRUCTION: Whelen M9 Scenelight With Flanges Above rear entry doors. Activate with rear entry doors and reverse. (1) On/off switch in the front switch panel.	1	
34-16-0800	X	Rr Bdy Lgts,(2) Mid-Hght, Whelen M9 LED, Red W/Flange INSTRUCTION: Red M9 Series With Flanges. To shine through rear windows when doors are open.	1	
34-38-0200		Warning Light Flash Requirements, "F-Spec" Flash Pattern	1	MAC
		* * * BODY DESIGN AND CONSTRUCTION COMPONENTS * * *	1	MAC
40-02-0001		Side Impact Beam (Std.) 8" x 2" x .25" side impact beam shall be welded to side body and sidewall extrusions to each side of the unit where the squad bench and CPR seats are located.	1	MAC
40-02-2800		Body Design & Construction, Alum, 168" L x 93.5" H x 96" W	1	MAC
40-07-0200		Compartment & Entry Doors With Door Liner Eberhard: 1033265 Outside locking handle 1033266 Inside locking handle 1033267 Inside NL handle 1033268 Outside NL handle Eberhard part numbers as follows: 1-21100-201K-03 Locking handle assy 21000-PK-30 Inside locking handle black tray 21000-PKNL -30 Black Finish Non locking inside 1-21100-03 Chrome plated handle, NL Outside	1	MAC
40-07-0300		Compartment Door, Inner Liner, ADP (Std.) Use .063 ADP inner door liner on all compartment doors.	1	MAC
40-08-1200		Exterior Compt. Depth, 18.75" (P5 20.75")	1	MAC

PART NO	S	DESCRIPTION	QTY	ID
		P5 20.75" P4 15.75" (if selected as an option.)		
40-10-0010		Protective Coating, Dolphin Microspray	1	MAC
40-10-0200		Insulation, Reflectix Dual Bubble INSTRUCTION: 3/8" Reflectix dual air bubble core insulation on walls and ceiling.	1	MAC
40-12-0200		Heat Shields, 18 ga. Galvanized Steel, LOCATION: Below Subfloor and to bottom of floor tubes	1	MAC
40-12-0300		Vapor Barrier, .063 aluminum LOCATION: Between the floor and the 2" x 2" floor tube structure	1	MAC
40-12-1200		Fender Insulator, Flash Patch Liner, Over Rear Wheelwells	1	MAC
40-14-2000		Cab Connection, 16 Gauge Steel, Crawl-Thru, Ford F-450 INSTRUCTION: EPDM rubber bellows held in place with rolled steel flexible cores	1	MAC
40-18-0400		Body Mounting, Isomount Technique, 3/4" x 6" Alum, 10-Bolt INSTRUCTION: 3/4" x 6" alum plates, ten (10) bolts. Bolts and paired rubber isolators with steel cap and collared mounting nut for each chassis manufacturer mounting point.	1	MAC
40-20-3150		EXTERIOR COMPARTMENTS -DRIVER SIDE (72" HR) PD-168-F AS	1	MAC
40-24-1100		D1, Exterior Compartment, 23" W x 84" H	1	MAC
40-32-0200		D1, Door, Solid, Vertically Hinged	1	MAC
42-02-2350		D2, Exterior Compartment, 51" W x 32" H	1	MAC
42-08-0200		D2, Doors, Double, Solid, Vertically Hinged	1	MAC
42-16-3900		D4, Exterior Compartment, 35" W x 69" H (Inside/Outside)	1	MAC
42-18-0200		D4, Doors, Double Solid, Vertically Hinged EXTERIOR COMPARTMENTS - PASSENGER SIDE LOCATION: Exterior compartments, passenger side	1 1	MAC MAC
44-03-0250		Side Entry Door, 32" W x 72" H With Dual Fire Grade ADP Step INSTRUCTION: Fire Grade ADP stepwell. Ahead of the ALS Compt.	1	MAC
44-03-3400	S	Door Panel, Side Entry, Three-Piece, Formica & Stainless Steel INSTRUCTION: Upper - Formica Center - Stainless Lower - Burnished Stainless Formica color to match interior. Lower Panels to be Burnished (Lochmandy)	1	MAC
44-04-2550		P1, Exterior Compartment, 24" W x 70" H, ALS (Action Safe)	1	MAC

PART NO	S	DESCRIPTION	QTY	ID
44-06-1000		P1, Door, Solid, Vertically Hinged	1	MAC
44-13-0100		Dual Fire Grade ADP Step	1	MAC
44-15-0100		Stepwell Light, Angled Pierce Style (2), LED Located on each side of the stepwell. Locate on the same side if there is interference on one side of the stepwell.	1	MAC
44-16-1600	S	Assist Handle, Yellow PowderCoat Antimicrobial LOCATION: Interior of side entry door. Antimicrobial assist handle	1	MAC
44-20-3110		P3, Exterior Compartment, Not Required At This Time	1	MAC
44-28-0010		P4, Exterior Compartment, Not Required at this Time	1	MAC
44-32-2300		P5, Exterior Compartment, 22" W x 84" H INSTRUCTION: Compartment walls lined with smooth aluminum and rubbermatted.	1	MAC
44-34-0200		P5, Door, Solid, Vertically Hinged	1	MAC
		* * REAR BODY PATIENT ENTRY DOORS * *	1	MAC
48-12-1000		Rear Entry Doors, 50" W x 63" H, Dual Tri-Mark Handles INSTRUCTION: Driver side - non-locking. Passenger side - locking.	1	MAC
48-14-3400	S	Door Panel, Rear Entry Doors, Three-Piece, Formica & Stainless INSTRUCTION: Upper - Formica Center - Stainless Lower - Burnished Stainless Formica color to match interior. Lower Panels to be Burnished (Lochmandy)	1	MAC
48-16-1200	S	Assist Handle, Yellow PowderCoat Antimicrobial LOCATION: Interior of rear entry door.	1	MAC
48-22-0600		(2) Gloveboxes Above Rear Entry Doors INSTRUCTION: Recessed into headpad. One on left side, one on right side. Flip up Plexiglas doors with Southco grabber catches at the bottom to secure.	1	MAC
48-24-1400		(1) Clock, Digital, Atomic, Above Rear Entry Doors LOCATION: Above rear entry doors, recessed in head pad. MFS-121 Clock. Medtec Part Number 1004458	1	MAC
		* * WINDOWS * *	1	MAC
49-02-0200		Sliding Window, Side Entry Door, OEM Tinted Glass INSTRUCTION: (1) 20" W x 19" H	1	MAC

PART NO	S	DESCRIPTION	QTY	ID
		Overall size: 20"wide x 19"high w/3.6875 radius / cutout size: 19.25"wide x 18.25"high w/3.25" radius.		
49-04-0200		Fixed Window, Rear Entry Door, OEM Tinted Glass INSTRUCTION: (2) 20" W x 19" H	1	MAC
		Overall size: 20"wide x 19"high w/3.6875 radius / cutout size: 19.25"wide x 18.25"high w/3.25" radius.		
		* * * EXTERIOR COMPARTMENT COMPONENTS * * *	1	MAC
50-00-0500		Exterior Compartments, ADP With "Sweep Out" Design ADP construction with sweepout on floor except rubberlined backboard compartment will have smooth aluminum.	1	MAC
50-02-0200		Exterior Compartments, Gas Charged Door Hold Opens LOCATION: On exterior compartment doors. Spring cam hold open on side entry door. Open greater than 90 degrees were applicable.	1	MAC
		Medtec P/N 1032471		
50-02-0600	S	Exterior Compartment Doors, Eberhard Latches INSTRUCTION: Custom Eberhard Latches	1	MAC
50-03-0000		Exterior O2 Vent - On O2 Compartment Door INSTRUCTION: (1) #1031 O/2 vent - exterior compt. door - of O/2 compt. (1) small black plastic vent - interior of compt. door on door liner.	1	MAC
50-04-0400		Exterior Compartments, Black Dri-Deck On Floor & Shelves Black Dri Deck with Safety Yellow End Cap.	1	MAC
50-06-0000		Rear Door Grabbers, Cast Products "Grabber" INSTRUCTION: Bottom of rear entry doors. For openings up to 145 degrees.	1	MAC
50-06-0400		Door Seals, Automotive Closed Cell Gasket LOCATION: Exterior compartments & entry doors	1	MAC
50-07-0300		Stainless Steel Door Sills - All Exterior Compartments INSTRUCTION: On upper ledge.	1	MAC
50-08-0200		Exterior Compartment Lights, Litco INSTRUCTION: Activated by compartment doors.	1	MAC

PART NO	S	DESCRIPTION	QTY	ID
EXTERIOR COMPARTMENT EQUIPMENT			1	MAC
50-10-0200		D1, (1) O2 Tank Mount, Stainless Steel Rings - "M" Cylinder INSTRUCTION: Adjustable	1	MAC
50-14-0200		D2, (1) Adjustable Shelf	1	MAC
50-16-1700		D4, (1) Adjustable Shelf	1	MAC
50-18-2500		P5, (1) Vert. Backboard Divider, Full Height, Spray Coated SPECIFY LOCATION: Full height spray coated divider. Centered in compartment	1	MAC
EXTERIOR BODY COMPONENTS			1	MAC
50-24-0600		Grab Rail, 16" - To The Left Of Side Entry Door	1	MAC
50-27-0400		Weld & Finish Side Seams	1	MAC
50-32-0800		Bumper, Rear With 7" Diamond Back Flip Step	1	MAC
50-34-0600		Bumper Pods, Cast Aluminum With Logo INSTRUCTION: Bumper pods will be even with the rear entry step end.	1	MAC
50-36-0800		Rear Kick Plate, Stainless Steel Above Rear Bumper Step Smooth Kickplate attached with Torx head screws and part of the body build. Stainless steel kickplate runs "hinge to hinge" width below rear entry doors. Rear hinge cover must match the kickplate.	1	MAC
50-36-1600		"ECK" Body Hardware Preparation	1	MAC
50-38-0600		Body Protection, Rear Mudflaps & "C" Channel Rubrails "Pierce" style "C" channel rubrails.	1	MAC
50-40-0400		Fuel Entry, Driver Side, Above & Behind Wheelwell	1	MAC
50-42-0400		Running Boards, Fire Grade ADP With Front Mudflaps	1	MAC
50-42-2800		Stoneguards, Stainless Steel, 21" Front - 16.5" Rear	1	MAC
50-44-0200		Fenderettes, Rear, Stainless Steel	1	MAC
50-46-0800		License Plate Holder #LP0002-1, Recessed On Driver's Side LOCATION: With (2) top lights. Rear drivers side, below turn signal.	1	MAC
50-50-0200		Ziebart Undercoating, Chassis & Body (Standard)	1	MAC
* * * INTERIOR PATIENT COMPARTMENT COMPONENTS * * *			1	MAC
52-05-0200		Cabinet Glass - Smoked Acrylic 1/4" Plexiglas	1	MAC
52-06-0200		Stainless Steel Round Locking SouthCo Latches, Standard INSTRUCTION: All interior cabinet doors to have, stainless steel round locking SouthCo latches.	1	MAC
52-10-0250		Cabinetry, Patient Compt, Wood With Formica (ACTION SAFE) 5" Rounded corner on HVAC cabinet	1	MAC
52-28-0500		Dome Lights, Whelen LED (8) INSTRUCTION: (2) - 3 position switches in the rear switch panel (1) for each bank of dome lights. A three-minute time delay system activated by the patient entry doors.	1	MAC

PART NO	S	DESCRIPTION	QTY	ID
		REF: 0500/2000/3300/3400 WHELEN P/N 80C0EECR		
52-28-0510		No Dome Light Dimmer for Whelen LED Dome Light	1	MAC
52-32-0200		Ceiling In Patient Compt, Pads Over Center Access INSTRUCTION: The ceiling to have access to antenna bases/leads. Covered by center ceiling pads.	1	MAC
52-36-0600		Thinlite Light, 18" - Surface Mount In 1st Action Area	1	MAC
52-40-0800		Thinlite Light 18" - Surface Mount In 3rd AA	1	MAC
52-54-2000		Flooring, With 5" Roll-up	1	MAC
52-60-0400		Rear Threshold, 6" Wide Stainless Steel With 2" Skid tape INSTRUCTION: 6" wide stainless steel threshold with 2" wide skid tape covering the threshold screw heads.	1	MAC
		INTERIOR COLOR SELECTION	1	MAC
53-02-1800		Formica Color, White (#949)	1	MAC
53-03-0400		Polished Formica Finish	1	MAC
53-06-1600		Flooring Color, Midnight #443, LonPlate II (Black)	1	MAC
53-33-0400		Upholstery Color,EVS Brand Gunmetal #MV102&#CN202 Brown/Grey INSTRUCTION: EVS Gunmetal #MV102 Vacuum Formed Cushions For The Following: Tech Seat, CPR Seat & Backrest, Squad Bench Seat & Backrest. Matching EVS Gunmetal #CN202 For All Trim.	1	MAC
		*** STREETSIDE CABINETS - PATIENT COMPARTMENT ***	1	MAC
54-02-8800		Sect 1 - Extended 1st Action Area With 3/4" Lip (AS) Streetside Action wall is to be polished white formica. Do not use brushed metal finish.	1	MAC
54-12-0200		Sect 1, Trintec Clock, 3.5" Battery Operated, 1st AA Angled INSTRUCTION: Install 3.5" battery operated Trintec clock mounted in the angled area, forward of the 1st action area switch panel.	1	MAC
54-16-2600		Sect 1, 1st Action Area Overhead Cabinet INSTRUCTION: Fixed center divider and (1) adjustable shelf on each side.	1	MAC
54-18-0600		Sect 1, Restocking Doors On Overhead Cabinet LOCATION: On the cabinet above 1st action area. Hinged on top.	1	MAC
54-20-0200		Sect 1, Handles, Full Length Aluminum LOCATION:	1	MAC

PART NO	S	DESCRIPTION	QTY	ID
		On the cabinet above 1st action area.		
54-26-4950		Sect 1, Computer Tray, 5" H x 14" W INSTRUCTION: Computer drawer below 1st action area. Round locking SouthCo latch to keep closed.	1	MAC
54-36-3200		Sect 1/2, No Cabinet Below 1st AA At This Time	1	MAC
54-36-3200		Sect 1/2, No Cabinet Below 1st AA At This Time	1	MAC
54-48-0800		Sect 1, Suction Cabinet, Pull-Out INSTRUCTION: Install a pull-out suction cabinet below the curbside action area	1	MAC
58-02-0800		Sect 3, Rearward Overhead Cabinet INSTRUCTION: Fixed center divider and (1) adjustable shelf on each side.	1	MAC
58-04-0600		Sect 3, Restocking Plexiglas Doors, Rear Overhead Cabinet	1	MAC
58-06-0200		Sect 3, Handles, Full Length Aluminum LOCATION: On the upper rear streetside overhead cabinet.	1	MAC
58-08-1000		Sect 3, Lower Rear Streetside Cabinet, (Inside/Outside) INSTRUCTION: Inside/outside access into D-4 compartment. Off set in D-4 for 2nd action area.	1	MAC
58-30-0200		Sect 3, Plexiglas Doors, Double Sliding LOCATION: Lower rear streetside main cabinet.	1	MAC
58-32-0200		Sect 3, Handles, Full Length Aluminum LOCATION: Lower rear streetside main cabinet.	1	MAC
58-46-0600		Sect 3, Exhaust Fan, 240 cfm Air Flow INSTRUCTIONS: Install (1) standard exhaust fan - streetside rear. Install a fan speed switch in rear switch panel	1	MAC
		*** BULKHEAD COMPONENTS ***	1	MAC
60-02-0200		B1, L/S, Oxygen Compt, Interior Access With O/2 View Window INSTRUCTION: Hinged plexiglas door for O/2 view into D-1 compartment.	1	MAC
60-02-0800		B1, L/S, Electrical Cabinet, Angled INSTRUCTION: An angled cabinet shall house the electrical components.	1	MAC
60-04-0200		B1, Electrical Cabinet Door w/Round Locking SS Southco Latch INSTRUCTION:	1	MAC

PART NO	S	DESCRIPTION	QTY	ID
		Door vented at the top and the bottom.		
60-08-0200		B1, Thermostat, Digital, Pro Air, PD&AD LOCATION: Curbside Action Wall (flush mounted on action wall-placement contingent on tube structure. Do not box out)	1	MAC
60-11-0400		B1/2, Cab/Body Crawl-Through LOCATION: Crawl-thru access between cab and module. Stainless steel threshold at edge of floor. (Bulkhead Door Deleted)	1	MAC
60-12-0600		B1/2, Heat/Cool Unit, Patient Compt, Pro-Air #935 INSTRUCTION: Mounted on bulkhead. Double vent on bottom of HVAC cabinet. HVAC Box to be 20"D	1	MAC
60-12-7000		B1/2, Action Safe HVAC NOTE! The double vent is on located on the SIDE of the HVAC cabinet.	1	MAC
		* * * PATIENT COMPARTMENT SEATING * * *	1	MAC
64-01-1200		Vacuumed Formed Upholstery PD & AD models INSTRUCTION: EVS Vacuum formed seats & backrests only. Armrests and all trim panels to be machine stitched using EVS Companion II material.	1	MAC
64-02-0200		Sect 1, Att. Seat, High Back, On SB185 Swivel Base, EVS (VF) INSTRUCTION: EVS vacuum formed high-back attendant seat. LH Armrest. EVS 188 swivel base -- 1700 series seat.	1	MAC
64-08-0110		Sect 2, Action Seat, HiBAC, 1780-5 EVS Seat, 5pt seat belt EVS Side Facing Seat with 5 Point Harness. Streetside and Curbside. Install Tube Structure above wheelwell for EVS seat during module fabrication.	2	MAC
		* * * CURBSIDE CABINETS - ACTION SAFE * * *	1	MAC
65-00-1000		Sect. 2 ALS Cabinet , 2-Section (Action Safe) INSTRUCTION: Top: Formica covered wood Top hinged door Locking round SouthCo latch. Lower: Dual Formica covered wood doors Locking round SouthCo latches and (2) adjustable shelves.	1	MAC

PART NO	S	DESCRIPTION	QTY	ID
		Rubbermat on the bottom of each cabinet section and shelf.		
65-10-2500		Sect 2, 3rd Action Area Control Center Angled Cabinet to match overhead angled cabinet in 3rd action area. Rear Switch Panel installed in 3rd Action Area	1	MAC
65-20-3050		Sect 2, 3rd AA Countertop Formica Countertop	1	MAC
65-50-0010		Sect. 3 Action Area rear of Action Seat, Std. (AS)	1	MAC
		*** CURBSIDE CABINETS - PATIENT COMPARTMENT ***	1	MAC
68-10-0110		Sect 2/3, No Squad Bench Cabinet (Head Protection Zone)	1	MAC
68-10-6000		Sect. 3, Action Safe Upper Cabinet, Two-Section (AS) INSTRUCTION:	1	MAC
		Installed to the forward and rear of the action seat.		
		Cabinets to be angled as much as possible to 45 degree from squad wall.		
68-12-0800		Sect 2/3, Restocking Plexiglas Doors, Sliding Flip Up LOCATION: On squad overhead cabinet.	1	MAC
68-14-1400		Sect 2/3, Handles, Full Length Aluminum LOCATION: On the squad overhead cabinet doors.	1	MAC
68-17-5000		Sect 3, Sharps/Waste, Under Action Area (Action Safe) INSTRUCTION: Drop in sharps and waste on countertop of forward curbside. Red plexi flip up lid with access to sharps and waste container.	1	MAC
68-17-5999	X	Sect 3, Curbside Drawers INSTRUCTION: Install 2 aluminum drawers (overlay) below curbside rear action area. Install (3) adjustable plexiglas dividers in each drawer Fab Part #1005646	2	
		*** PATIENT COMPARTMENT EQUIPMENT/COMPONENTS ***	1	MAC
70-02-1200		IV Holders, (4) Cast Products #2008-1, Ceiling - Head/Foot LOCATION: (2) over cot (2) over squad bench	1	MAC
70-10-0400		Cot Mount, Stryker #6377 Dual Position, Floor Mount INSTRUCTION: For Cot Model: _____ (for positioning of cot mounts only)	1	MAC
70-14-0600		Cot Mount Location, Side & Center	1	MAC
70-17-0200		No Cot Stop Required at This Time	1	MAC
72-02-1800	S	Assist Rails,(1)90"x1.25"(1)60"x1.25"Yellow Antimicrobi INSTRUCTION: (1) 90"x 1.25" - over cot. (1) 60" x 1.25 " - over squad bench.	1	MAC
		Yellow PowderCoated Antimicrobial finish		

PART NO	S	DESCRIPTION	QTY	ID
72-10-0200		Signs, "No Smoking Oxygen Equipped" & "Fasten Seatbelts" LOCATION: (1) on 1st action area wall.	1	MAC
		* * * MEDICAL OXYGEN & ENVIRONMENTAL SYSTEMS * * *	1	MAC
74-02-0200		Oxygen, 3000 Liters Minimum	1	MAC
74-02-0650	S	Oxygen, (3) Outlets - (1) AA, (1) Curbside, (1) Ceiling INSTRUCTION: (1) 1st AA (1) Squad Bench (1) Ceiling SEE PRINTS NOTE: Please leave a minimum of 5 INCHES to accommodate the larger gauge (flowmeter)	1	MAC
74-04-0800		Oxygen Outlets, Ohio Style	1	MAC
74-06-0600		Flowmeter, (1) Oxygen, Gravity Type LOCATION: SHIPPED LOOSE	1	MAC
74-10-0600		Regulator, Oxygen LOCATION: On O/2 hose in designated oxygen compartment.	1	MAC
74-20-0900		Suction & Aspiration Systems, SSCOR/Thomas, 3rd AA (AS) INSTRUCTION: (1) SSCOR 20001/02 disposable canister, SSCOR SS bracket and wall-mount SSCOR 23001 vacuum gauge and outlet on 3rd action area wall. Install the Thomas brand vacuum pump in the upper left corner of the D-2 compartment, in a metal cage. (1) "on/off" switch in the rear switch panel, for Suction pump. SEE PRINTS REF: 2000/3400/3500/3600	1	MAC
74-22-0200		Sharps & Bio-Hazard Containers, Racksack With Bags LOCATION: SHIPPED LOOSE	1	MAC
		* * * COMMUNICATION & LOOSE EQUIPMENT * * *	1	MAC
76-02-0400		Patient Code Signal System, With (3) Switches & Buzzer LOCATION: Cab console and rear switch panel.	1	MAC
76-06-0200		Radio Antenna Pre-Wire, (2) Base, Power, Ground & Coax INSTRUCTION: Antenna/Radio (2) bases and coax. Power and ground wires. Run from: (1) Center front of module roof. (1) Center center of module roof. Run to: Both to behind passenger seat in cab. Large gauge wire used for all radio power wiring. Wiring includes	1	MAC

PART NO	S	DESCRIPTION	QTY	ID
		(1) 8 gauge battery hot wire		
		(1) 8 gauge Ignition hot wire		
		(1) 14 gauge Ground wire		
78-02-0600		(2) Fire Extinguishers, ABC 5 lb With Mounting Brackets LOCATION: SHIPPED LOOSE	1	MAC
		*** PAINTING, LETTERING & STRIPING ***	1	MAC
80-04-0200		Body Surface Preparation with Corrosion Inhibitor	1	MAC
80-04-0400		Paint Preparation & Processes	1	MAC
80-04-0800		Body Paint Color, Sikkens, Single, White	1	MAC
83-00-0100		Entry Door Perimeter Safety Stripe, White Reflective (Std.) Install a white reflective perimeter safety stripe around each entry door.	1	MAC
84-05-0200		No Vehicle Stripe Design Required At This Time	1	MAC
84-07-0000		Non Metallic or Pearl Paint Color	1	MAC
84-22-0000		Pinstripe, 3/4" W -"C" Style Rubrail, Reflective INSTRUCTION: Install 3/4" wide white reflective stripe through the center of the "C" style rubrail.	1	MAC
88-04-0400		Decals, "Ambulance" & "Star of Life" Pkgs, SHIPPED LOOSE Roof SOL Avery Vivid Blue 9570-O	1	MAC
88-12-5400		Medtec Decals, (2) Medtec Logo, Cardinal Red INSTRUCTION: "MEDTEC" - Avery Cardinal Red A6330-O (1) Streetside Body, (1) Curbside Body.	1	MAC
		*** DELIVERY / END USER DOCUMENTATION ***	1	MAC
90-02-0100		Vehicle Operator's Manual, Hard Cover Binder - Ford	1	MAC
90-06-0600		Operating Instructions, DVD	1	MAC
90-06-0800		Electrical Schematics CD	1	MAC
90-07-0200		Fuel Fill	1	MAC
92-02-0200		Medtec Standard Warranty	1	MAC
92-06-0400		No Extended Conversion Warranty Required	1	MAC